

Interior Sheen Emulsion

PRODUCT DESCRIPTION

Indigo Interior Sheen Emulsion Bronze Series gives a soft sheen finish at an economical price and outperforms an acrylic distemper in terms of hiding & coverage.



PERFORMANCE FEATURES & BENEFITS

- Soft Sheen Finish
- Value For Money
- Better hiding & coverage compared to distemper

FINISH

MATT **SOFT SHEEN FINISH**

WASHABILITY

NA **LOW** MEDIUM HIGH

RECOMMENDED USES

AREA



INTERIOR



EXTERIOR

SURFACES

Freshly prepared Cement Plaster as well as completely cured cement plaster.

APPLICATION DETAILS & SURFACE PREPARATION

MIXING



Stir well before use.

TOOLS



Brush, Roller & Spray

THINNING



Water

THINNING RATIO

1 liter of paint with 450ml of clean water

SURFACE DRYING TIME



4 Hours

MIXING RATIO

NA

FILLING



Indigo polymer putty or Acrylic putty

APPLICATION ENVIRONMENT



Temperature
10-40 degree Celsius.
Humidity below 70%

CLEANING



Ensure that surface is completely free from all dirt, loosely held plaster, powdery residue, oil grease or any other contamination.

SURFACE PREPARATION



Fill dents in the surface using 2 coats of Indigo Polymer putty .Allow to dry & apply one coat of Indigo WT cement primer .Allow to dry.

APPLICATION



Apply 2-3 coats of Interior Sheen Emulsion Bronze Series obtained by thinning 1 liter of emulsion with 450 ml water

SAFETY FEATURES



Safety features
Non- flammable,
no added lead mercury
or chromium compound.

TECHNICAL DATA

Coverage	1 coat - 14-15 sqm/ltr 2 coats - 8-9 sqm /ltr
Drying Time	4-6 hours
Sheen level	40 @ 85 degree
Flash point	NA
Stability of thinned paint	24 hours
Appearance	Smooth white liquid
Solids	45%
Specific gravity	1.34
Recommended DFT	NA
Viscosity	1500 CP @30°C by Stormer viscometer
Pot life	NA
Shelf life	36 months
Contrast ratio	96%

**Practical Spreading Rate will vary from the quoted Theoretical Spreading Rate due to factors such as method and condition of application as well as surface roughness.*

PRECAUTIONS

1. Do not apply when the ambient temperature is below 10°C
2. Do not apply directly on lime wash or White cement painted wall.
3. Shake well before use and do not over dilute
4. Keep the container tightly closed to prevent drying.

POST APPLICATION INSTRUCTIONS

NA

AVAILABLE PACK SIZE

Available in:



SHADE RANGE

White & Colors as per spirit fan deck



INDIGO
Be surprised!

FOR BEST RESULTS

FOR EXTERIOR EMULSIONS / PRIMERS

- Stir well and strain before use.
- Do not apply paint when ambient temperature is below 10°C or higher than 45°C or there are chances of such temperature within 4 hours of application.
- Ensure the surface/walls to be painted has dried properly. For new surfaces ensure the plastered walls have cured for 6-8 weeks before painting.
- Remove loose / flaky paint.
- Remove all traces of algae fungus dust & dirt by using a pressure wash and wire brush. It is essential that all traces of contaminants are removed properly for longer life of the new coating. Areas with heave algae growth will need to be treated with a bio wash after thorough cleaning.
- Leaks, if any, must be traced and treated. Any source of constant dampness leads to accelerated growth of algae/fungus.
- Cracks to be sealed. Non-structural cracks can be sealed using a good quality crack seal. For structural cracks take the advice of a Structural engineer.
- Check for efflorescence (white dust on rubbing the wall with your hand). If present should be treated with an anti-efflorescence primer like Indigo WT Sealer Primer. If this is not treated then the new coating being applied will have inferior adhesion.
- Ensure that Indigo Paints tinting machine and machine colourants have been used to produce the shade selected. Ensure that tinted paints are mixed thoroughly.
- Ensure painting is completed before rains. Exposing primer coat or primer coat plus one topcoat to the rain will adversely affect the performance of paint system.
- Always ensure three coats of the topcoat on sunshades and horizontal surfaces. Also ensure the horizontal surfaces are coated first before the vertical to avoid streak marks.
- Do not overthin the paint. And always use good quality water for thinning, chlorinated water is not recommended.
- Thinned paint must be consumed within 24 hours of dilution, after which there are high chances of bacterial growth.
- When using colours that have been tinted in different batches of any emulsion, it is always advisable to mix the batches together and then apply the colour at site. There may be very small variations in colour between batches and this may be more evident when applied side by side or during touch up.
- Dark colours in emulsions are tinted using clear bases, hence the hiding of these shades will be inferior when compared to lighter shades (shades tinted in the first base). Such dark shades may require three-four coats, without dilution, to ensure proper hiding OR the primer will have to be tinted in this shade, followed by two-three coats for proper hiding.
- Only fine (using less pressure) sanding should be done over Polymer Putty & Waterproof Polymer Putty, using abrasive paper grit no.120 or higher. Sanding using rough emery paper or high pressure will break the polymer film formed & lead to adhesion/water repellancy issues.
- Paint should not be applied as a thick coat, especially in corners.

FOR INTERIOR EMULSIONS / PRIMERS

- Stir well and strain before use.
- Do not apply paint when ambient temperature is below 10°C or higher than 45°C or if there are chances of such temperature within 4 hours of application.
- Ensure the surface/walls to be painted has dried properly. For new surfaces ensure the plastered walls have cured for 6-8 weeks before painting.
- Sources of leak must be identified, fixed and allowed to dry completely before painting.
- During repainting, all loose, flaky material must be removed and the walls cleaned before application of fresh paint.
- Sheen emulsions have a tendency to reflect light, hence the surface must ideally be free of undulations to the extent possible for best results. Otherwise, all the undulations/uneven areas in the wall will be highlighted when light reflects off the wall.
- In case of Premium, Luxury emulsions and Acrylic Laminate, if masking tape is used to separate the areas being painted then the masking tape must be removed immediately after application, when the paint is still wet. Else there are chances of the paint peeling off along with the tape.
- Always ensure primer is applied over putty before application of the topcoat. This will ensure a more even finish and also improve coverage of the topcoat.
- Ensure that Indigo Paints tinting machine and machine colourants have been used to produce the shade selected. Ensure that tinted paints are mixed thoroughly.
- When using colours that have been tinted in different batches of any emulsion, it is always advisable to mix the batches together and then apply the colour at site. There may be very small variations in colour between batches and this may be more evident when applied side by side or during touch up.
- If unused paint is to be stored, then it must be not be diluted with water. It must be stored in an undiluted condition in an air tight container and kept in a cool and dry space. If the emulsion has been diluted with water, then it must be used within 24 hours.
- Dark colours in emulsions are tinted using clear bases, hence the hiding of these shades will be inferior when compared to lighter shades (shades tinted in the first base). Such dark shades may require three-four coats, without dilution, to ensure proper hiding OR the primer will have to be tinted in this shade, followed by two-three coats for proper hiding.
- Only fine (using less pressure) sanding should be done over Polymer Putty & Waterproof Polymer Putty, using abrasive paper grit no. 120 or higher. Sanding using rough emery paper or high pressure will break the polymer film formed & lead to adhesion/water repellancy issues.
- Paint should not be applied as a thick coat, especially in corners.